

Has filament stopped flowing out the nozzle?

Article Number: 16 | Rating: Unrated | Last Updated: Thu, Jun 6, 2019 at 9:51 PM

There could be some residual filament left over. Glenn and Gabe show you up-close how to clear the jam in your nozzle. This procedure works on the GorillaMaker GM3D200, GM3D250, and GM3D505.

Requires the brass rod located in your tool-kit.

Posted by: **Shelley Warner** - Thu, Jun 6, 2019 at 9:51 PM. This article has been viewed 221 times.

Online URL: <http://gorillamaker.knowledgebase.co/article.php?id=16>