

# How to clear a blinking error on your GorillaMaker #3dPrinter

Article Number: 7 | Rating: Unrated | Last Updated: Sun, Dec 10, 2017 at 7:20 PM

Is your probe blinking? If the bed was too close to the probe when it was turned on will cause the light on the probe to blink.

To Reset your sensor probe-

- Tap Home
- Tap Home All

Your 3d printer will now home and automatically reset your probe light.

Posted by: [Shelley Warner](#) - Sun, Dec 10, 2017 at 7:20 PM. This article has been viewed 1289 times.

Online URL: <http://gorillamaker.knowledgebase.co/article.php?id=7>